

Shark Electricals

# USER GUIDE The Timer Plug Socket

# Content

1	Introduction2
2	Installation 3
3	
Set	tingsError!
Во	okmark not defined.
	Power switch
	Rotary encoder
	Display
	Two-way switch
4	Power supply 6
5	Features7
	Usability
	Restrictions
6	Contact Us

Thank you for selecting shark Electricals. This device provides an extra functionality to your home appliances to save time & energy. Please go through the following instructions before use.

### 1. Introduction

Your Timer switch connects to your home plug socket to optimize the power input to a pre-scheduled time frame. You can setup the device to automatically power off according to your desire.

Device connects to 230V household power input & convert the voltage AC to DC. DC voltage inside the device provides the operating power to the switch. User can change the time of operation accordingly.



### 2. Installation

Device comes with two options for installation.

- Connect the device directly through the wall to main supply.
- Connect to a 13A plug socket through the cable in the hox

## 3. Settings

### Power switch

User can turn on & off the device without considering the timer operation.



### **Rotary Encoder**

Rotate to setup the timer. Time can be adjusted in steps of 5 seconds.

Rotate clockwise (CW) to set the time.





### Options comes under rotary encoder:

### After time is set,

- Single Press Switch is on & Timer is counting.
- Single press while timer on Timer pauses.
- Single press after pause operation Timer resumes.
- Double press after pause operation Timer reset.
- Triple press while timer on Timer reset.

### **Display**

Seven segment display is used as an indicator the status of the device.

### Display commands:

- Hello Timer is on.
- 0000 Timer is set.
- Paus Timer is paused.
- End Timer operation is finished.



Timer is on.



Timer is set.



Timer is paused.



Timer operation is finished.

### Two-way switch



Timer facility of the switch can be disabled manually when you are not using it as a timer switch.

# 4. Power Supply

230 Volts household power supply is used as the main source.

### Power conversion devices:

- AC-DC convertor convert 230V into 5V.
- Buck convertor convert 5V to 3.3V.

### 5. Features

### **Usability:**

- Can set up to 100 minutes.
- Reset function is available.
- Time can be set according to user's preference.
- Availability of pause option to stop the timer any time.
- Can be used as a mobile switch base.
- Save energy wastage in your households.

### **Restrictions:**

- Use the power switch to switch off the device in emergencies.
- Do not connect to higher voltages more than 230V.
- After a one cycle timer is automatically setup into the previously given time for another cycle if user need.

### 6. Contact Us

www.facebook.com/sharkelectricals

Tel: +94 91 2250078